



Benchtop should have an overhang all around to allow clamping things down

Detail: All board connections
...except benchtop.
Do not screw through the benchtop into the stave, but from the bottom into the benchtop through the pre-drilled stave

Sequence: first glue+screw stave to sheet B (watch that both remain true along their length), then glue+screw both to sheet A (or sheet A to both)

